

Lock Depot Inc

SecuraKey e*ACCESS Quick Start

e*ACCESS Single-Door System

The e*ACCESS system provides affordable standalone access control for single-door applications. Includes SK-ACP panel, proximity reader, and initial credential set.

Installation Steps

- **Power Supply:** 12VDC, 2A minimum. Use regulated power supply for optimal performance
- **Reader Wiring:** Connect reader via 4-conductor cable (power+, power-, data+, data-)
- **Lock Output:** Relay configuration connects to electric strike or maglock driver
- **REX Connection:** Request-to-Exit button wired to open contact, allows free egress

Programming First Credential

Hold programming key to panel for 5 seconds (green LED). Present first credential to reader. Credential enrolls as master card. All subsequent credentials require master card to enroll.

Output Configuration

Lock output relay can operate in two modes: momentary (0.5 second pulse for electronic strikes) or latching (sustained contact for maglock integration). REX input normally energizes lock (true fail-safe).